



NOTES:

1. PRIOR TO EXECUTING INSIDE CORNER DETAIL, REFER TO APPROPRIATE UNIFLEX SYSTEM SPECIFICATION.
2. USING 12"x12" POLYESTER FABRIC, ALINE MIDDLE OF POLYESTER FABRIC WITHIN CORNER. (POLYESTER FABRIC SHOULD EXTEND 6" ONTO EACH PARAPET WALL.) CUT FABRIC WILL OVER LAP ONE ANOTHER TO FIT INTO CORNER.
3. POLYESTER FABRIC SHOULD FIT SECURELY AGAINST CANT STRIP AND WALL.