



Apply Uniflex Sealant at wall to field membrane overlap at 60 wet mils extending 2 inches on either side of membrane seam

Notes:

1. Surface must be clean , dry and in sound condition prior to application.
2. Refer to the Uniflex Specification for appropriate sealant or coating.