



1. Surface must be clean , dry and in sound condition prior to application.
2. Remove clamping ring and reinstall after applying sealant.
3. Refer to the Uniflex Specification for appropriate sealant or coating.