



INSPECT SEALANT

Replace with temperature appropriate sealant as necessary.

UNIFLEX SEALANT

Seal flashing collar with Uniflex Sealant, extending 3 inches on the vertical and horizontal surfaces.

Notes:

1. Surface must be clean , dry and in sound condition prior to application.
2. Apply appropriate Uniflex Rust Inhibitive Primer prior to application if corrosion is present.
3. Refer to the Uniflex Specification for appropriate sealant or coating.