



STEP 1

POLYESTER FABRIC CORNER PIECE FULLY EMBEDDED INTO UNIFLEX BASE COAT


RELIEF SLITS



STEP 2

POLYESTER FABRIC FULLY EMBEDDED INTO UNIFLEX BASE COAT

POLYESTER FABRIC FULLY EMBEDDED



STEP 3

NOTES:

1. SURFACE MUST BE CLEAN, DRY AND IN SOUND CONDITION. REMOVE ALL OIL, GREASE, DUST, DIRT, LOOSE RUST AND OTHER FOREIGN MATERIAL TO ENSURE ADEQUATE ADHESION.
2. APPLY UNIFLEX RUST INHIBITIVE METAL PRIMER PRIOR TO REPAIRS AND COATING IF METAL SURFACE OXIDATION IS PRESENT
3. REFER TO APPROPRIATE UNIFLEX PREMIUM ELASTOMERIC SPECIFICATION.



UNIFLEX PREMIUM ELASTOMERIC SYSTEM  
TYPICAL OUTSIDE CORNER FLASHING DETAIL

NOT TO SCALE

DATE: 3/25/11

SHEET NO:

OC-1